COOKIES AND MILK INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)

- 3 Point Controller
- 2 Ground Stakes
- 2 Bolts
- 4 Nuts
- 1 Package of Color Clips (replacement)

1. Unfold display being careful to not stretch any attached wires.
2. Ensure the item is unfolded. Then, using bolts and nuts attach items if needed or provide support at the hinges where it is called for.
3. Attach the ground stakes to the provided bottom slots using the remaining two nuts.
4. Next, gently push ground stakes into the ground. You can do this using your foot and a back and forth motion to inch each side gradually into the ground.
5. To begin plug instructions, use the three point controller at the bottom of the arrow to attach male plugs into the controller as the picture below shows. Plug in male end of the controller to the extension cord.
6. Lastly, plug in the last male plug that is to the middle right of the bottom of the display.

