Dinosaur with Hatching Baby Instructions

Please check that you have all parts. (Located in attached bag)

- 6 ground stakes
- 1 pkg. of asst. color clips (replacement)
- 3 Wing bolts
- 9 Wing nuts
- 1 gray 2 point controller

Unfold display being careful not to stretch any attached wires. There are 3 hinges on the display. Attach two small metal plates at hinge together by screwing wing bolt into metal plates to hold up display. Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench. Dinosaur will need extra support which is not included. You can do this with an extra stakes placed behind the display, driven into the ground, and tied to the frame using a twist tie or a cable tie. Push ground stakes gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground.

Adjust speed to your liking

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers.

