HO HO HO WALKWAY ARCH INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)
- 4 ground stakes with wingnuts
- 1 pkg of asst, color clips (replacement)
- 9 Wingbolts with nuts
- 3 6ft jumper cords
- 1 gray 3 Point Animation Controller

THIS ITEM WILL NEED EXTRA SUPPORT WHICH IS NOT INCLUDED.

Unfold display being careful not to stretch any attached wires.

Large Decorations are best assembled while lying face down on the ground.

Attach two small metal plates at hinge together by screwing wing bolt into metal plates to hold up display. Attach ground stakes by placing them into the bottom provided slots and use wing nut to tighten. Push ground stakes gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground.

1. Plug SANTA ARCH (unmarked plug) into an extension cord.
2. Plug controller into an extension cord.
3. There are 3 plugs coming from EACH “HO”, each labeled Green 1, Red 2, and Yellow 3. Plug the Green 1 into the Green 1 on the controller, plug the Red 2 into the Red 2 slot on controller, and plug Yellow 3 into the Yellow 3 slot on controller.

Adjust speed to your liking

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers.

