

FALLING SNOWFLAKE

INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)


- 1 pkg of asst. color clips (replacements)
- 1 black 4 point controller (may be already attached to decoration)

The Falling Snowflake is a hanging item. This can be hung just as you would a wreath. You can use a nail or screw to do this.

All four snowflakes plug into the black 4 point controller. Each one is labeled Green 1 and Red 2 and Yellow 3 and Blue 4. First plug the controller into an extension cord. Then plug the Green 1 into the Green 1 on the controller. Plug the Red 2 into the Red 2 on the controller. Plug the Yellow 3 into the Yellow 3 on the controller. Plug the Blue 4 into the Blue 4 on the controller. Make sure that each set of lights is flashing one at a time before you move to the next plug.

*** If you plug any of these into the controller and the light does not come on, for example, you plug up Green 1 to Green 1 and the set of lights does not come on, you need to turn that plug around. Some controllers have a polarity issue. IF the polarity is crossed it will not light. So by turning the prongs around, it will line up the polarity and the lights will come on. We have also placed a dot on the controller plug and a dot on the decoration plug. If you line these dots up, then it will keep the polarity straight.

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers. See our website for ideas on how to protect your controller. www.christmasdonebright.com



plug controller to extension cord