

PENGUIN FISHING INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)

- 4 ground stakes
- 1 pkg of asst. color clips (replacement)
- 1 black 2 point controller (may be already attached)

Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench.

Push ground stakes gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground.

First plug the penguin to an extension cord (not included) Then plug in the water hole (non animated part) into the back of the penguin plug. The plugs will be stacked.

Then Plug in animated parts. ***First plug the controller into an extension cord. The fishing poles use the 2 point controller. Two male plugs are labeled Green 1 and Red 2 . Plug the Green 1 into the Green 1 on the controller. Plug the Red 2 into the Red 2 on the controller. Adjust speed to your liking

*** If you plug any of these into the controller and the light does not come on, for example, you plug up Green 1 to Green 1 and the lights do not come on, you need to turn that plug around.

Some controllers have a polarity issue. IF the polarity is crossed it will not light. So by turning the prongs around, it will line up the polarity and the lights will come on. We have also placed a dot on the controller plug and a dot on the decoration plug. If you line these dots up, then it will keep the polarity straight.

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers. See our website for ideas on how to protect your controller.

plug to extension cord

