

SANTA'S DUMPTRUCK

Please check that you have all parts. (Located in attached bag)

- 4 ground stakes
- 2 wing bolts, 6 wing nuts
- 1 pkg. of asst. color clips (replacement)
- 1 Large 2 point controller

Unfold display being careful not to stretch any attached wires. There are two pieces to the Dump Truck. One is whole Dump Truck. One is Dump bed with no front of the truck. There are hinges on the whole truck. Attach two small metal plates at hinges together by screwing wing bolt into metal plates to hold up display. Make sure bolt is on opposite side of the nut which is attached. Do not screw bolt into the side with the nut first.

Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench.

Dump Truck may possibly need extra support which is not included. You can do this with an extra stakes placed behind the display, driven into the ground, and tied to the frame using a twist tie or a cable tie. Push ground stakes of whole dump truck gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground. Then directly behind of this whole dump truck, place the bed only. Attach two together with cable tie or twist tie.

1. Plug front section of the whole dump truck into an extension cord. This male plug is not marked.
2. Plug controller into an extension cord. (Not included.)
3. There are two male plugs at the bottom of each dump bed marked either Green 1 or Red 2.
4. Plug Green 1 into Green 1 on the controller. Plug Red 2 into Red 2 on the controller. Adjust speed to your liking.

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers. See our website for ideas on how to protect your controller.

