

# SANTA'S TRACTOR

Please check that you have all parts. (Located in attached bag)

- 2 ground stakes
- 1 pkg. of asst. color clips (replacement)
- 1 gray 3 point controller

Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench. Push ground stake gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground

1. Plug Tractor body (not wheels) into an extension cord (not provided). The wheels are the only parts that plug into the gray 3 point controller.
2. Each one is labeled Green 1 and Red 2 and Yellow 3. First plug the controller into an extension cord. Then plug the Green 1 into the Green 1 on the controller. Plug the Red 2 into the Red 2 on the controller. Plug the Yellow 3 into the Yellow 3 on the controller. Make sure that each set of lights is flashing one at a time before you move to the next plug.

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers.

