

# 3-D CHRISTMAS TREE

Please check that you have all parts. (Located in attached bag)

- 1 pkg. of asst. color clips (replacement)
- 24 bolt's
- 12 ground stakes
- 18 brackets
- 36 wing nuts

1. Unfold display being careful not to stretch any attached wires. There are 6 pieces to the 3 D Tree. There are hinges on each one. Attach two small metal plates at hinges together by screwing wing bolt into metal plates to hold up display.
2. Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench.
3. Lay three halves on the left side on top of each other and 3 on the right. It will look like a flat Christmas tree lying on the ground.
4. Push centers together and use a cable tie to strap them together in the center top middle and bottom.
5. Raise the tree. After raised, fan out all sides.
6. Starting at the top, put brackets together with bolts provided.
7. Then put the brackets in the middle and then the bottom. You can then push the tree from all sides into the ground. All of the plugs are in the center of the tree and are stackable. Plug into an extension cord.

For the best look, straighten clips.

