

DRUMMING ELEPHANT

Please check that you have all parts. (Located in attached bag)

- 1 wing bolt
- 3 wing nuts
- 2 ground stakes
- 1 pkg of asst. color clips (replacement)
- 1 gray 2 point controller

1. Unfold display being careful not to stretch any attached wires. Attach two small metal plates at hinges together by screwing wing bolt into metal plates to hold up display.
2. Place ground stakes in provided slots and use wing nut to secure into place.
3. Push ground stakes gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground.
4. Plug Elephant body into an extension cord. (Male plug not marked.)
5. Plug the controller into an extension cord (not included.)
6. There are two plugs coming from the drum sticks each marked Green 1 and Red 2. Plug Green 1 into Green 1 on the controller. Plug Red 2 into Red 2 on the controller.
7. Adjust speed to your liking. Straighten clips for best appearance.

