ELF BROTHERS INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)

- 2 Point Controller
- 4 Ground Stakes
- 3 Bolts
- 7 Nuts
- 1 Package of Color Clips (replacement)

1. Unfold items being careful to not stretch any attached wires.
2. The items have hinges and attachment spots where you'll need to use bolts and nuts to screw together to hold the display up.
3. Attach ground stakes into the provided bottom slots using the remaining four nuts.
4. Next, gently push ground stakes into the ground. You can do this using your foot and a back and forth motion to inch each side gradually into the ground.
5. To begin plug instructions, you will need an extension cord. On the left elf with waving arms, you will need to attach the controller. To do this, there will be two male plugs coming from his upper body that can be plugged into the female plugs on the controller.
6. Then, plug the controller into the extension cord. There will also be a plug from the left, upper body of the right elf to plug in. Lastly, there is a plug near the foot of the left elf to plug into the extension cord. (See attached picture below for help if needed)

For the best look, straighten clips. Also, if you live in an area with a lot of snow or rain, you may want to take extra precaution to cover controllers. See our website for ideas on how to do this.

