



Bow & Bells

1. Test all decorations before plugging into controller.
2. Bow and Bells have 3 cords coming from the center.
3. Bow does not plug into controller.
4. Bells plug into controller as shown below



Plug Green 1 into Green 1
Plug Red 2 into Red 2
Other plug goes into extension.
Plug controller into extension cord.

A diagram showing a 2-point controller plug connected to an extension cord. The controller is a black square with two prongs, labeled 'sm 2 point controller'. The extension cord is a thin line with a 2-point plug at the end, labeled 'ext. cord'. An arrow points from the text 'Plug controller into extension cord.' to the controller plug.

***see below about polarization issues.

*** If you plug any of these into the controller and the light does not come on, for example, you plug up Green 1 to Green 1 and the lights do not come on, you need to turn that plug around.

Some controllers have a polarity issue. IF the polarity is crossed it will not light. So by turning the prongs around, it will line up the polarity and the lights will come on. We have also placed a dot on the controller plug and a dot on the decoration plug. If you line these dots up, then it will keep the polarity straight.

For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers. See our website for ideas on how to protect your controller.