SANTA SLEIGH WITH 3 DEER

INSTRUCTIONS

Please check that you have all parts. (Located in attached bag)

- 8 ground stakes
- 1 pkg of asst. color clips (replacement)
- 1 black 2 point controller
- 1 cord set

Attach ground stakes by screwing them into the bottom provided slots on the deer and the sleigh. You may need an adjustable wrench.

Push ground stake gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground. Do this for the sleigh all three deer. After you have it set up in the ground, place the cord set on the ground (behind the decoration looks best).

1. First, starting at the back of the sleigh, plug the cord set into an extension cord. (not provided)
2. Then at the first female plug on the cord set , plug the black controller into this female outlet.
3. You will see two male plugs marked Green 1 and Red 2. Plug these into the Green 1 female outlet on the controller and the Red 2 outlet on the controller.
4. The sleigh and each deer have 3 male plugs at the bottom. One is not labeled (this will light the bodies that are not animated) and two are labeled Green 1 and Red 2. For the sleigh and each deer, match each of the male plugs on the decorations to each female plug on the cord set. *** (please see below for polarity issues)
5. You can adjust the speed on the controller to your liking.

*** If you plug any of these into the controller and the light does not come on, for example, you plug up Green 1 to Green 1 and the lights do not come on, you need to turn that plug around. Some controllers have a polarity issue. IF the polarity is crossed it will not light. So by turning the prongs around, it will line up the polarity and the lights will come on. We have also placed a dot on the controller plug and a dot on the decoration plug. If you line these dots up, then it will keep the polarity straight

. For the best look, straighten clips. Also, if you live in an area with lots of rain or snow, you may want to take extra precaution to cover your controllers. See our website for ideas on how to protect your controller.

Plug to extension cord

controller plugs here

cord set